



OVERVIEW

EVO FLEX


EVO FLEX

CLIPS (6x)





EVO FLEX

1/2/3





EVO FLEX

CORNER OUTSIDE





EVO FLEX

CORNER INSIDE




EVO FLEX

DRIVER 1





EVO FLEX

-EXT CORD 1




EVO FLEX

PROFILE



OVERVIEW



CHOOSE LENGTH

ADD ACCESSORIES

$$\begin{array}{ccccccc} & 2 & & & & & \\ 1 & + & 3 & + & 5 & t/m & 9 + 10 \\ & 4 & & & & & \end{array}$$


START WITH

USE WHEN CUT


- * ONE DRIVER PER FLEX IS NEEDED
- * NOT POSSIBLE TO CONNECT MULTIPLE FLEX

OVERVIEW
EVO FLEX


TEMPORARY FIXING




PLACING THE FLEX




CUTTING THE FLEX



PLACING DRIVER (OPTIONAL)



ATTACHING PROFILE




OVERVIEW


EVO FLEX




1x
EVO FLEX
1



2x
EVO FLEX
2



1x
EVO FLEX
3



4x
EVO FLEX
DRIVER 1



6x
EVO FLEX
CLIPS



6x
EVO FLEX
PROFILE



1x
EVO FLEX
CORNER OUTSIDE



1x
EVO FLEX
CORNER INSIDE

